




Yamaha YFZ 450R Factory Replacement Air Filter OTR PART# OR10524

OTR Air Filters are specifically designed and engineered in order to provide maximum performance and engine protection for your Yamaha ATV. Positive filter sealing and ultra-high efficiency media ensure that no dust enters your engine.


1. Remove existing wing bolt, air filter, and plastic guide
2. Install OTR rubber washer to the existing wing bolt and washer (See Image)
3. Install the wing bolt into the OTR Air Filter (See Image)
4. Hand tighten the wing bolt into the existing holder securing the OTR Air Filter in place





Install OTR
Rubber Washer
onto the existing
wing bolt

OTR Air Filter



Filter Maintenance

Normal Maintenance - Clean filter as required using low pressure compressed air (50-70 psi) directed from the inside (clean) surface toward the outside (dirty) surface.

Discoloration and staining will occur over time. This will not impact filter restriction and efficiency. Compressed air cleaning will restore the filter's performance. OTR air filters are washable using a biodegradable cleaner such as Simple Green. Soak, rinse and allow plenty of time to dry.

Follow dilution instructions for *light cleaning* products made with aluminum.

Never oil an OTR filter as this will only degrade the filter's performance.

OTR FILTERS
605 Tower Road
Mundelein, IL 60060
800-263-8660