




Honda TRX 450 Factory Replacement Air Filter PART# OR10526

OTR Air Filters are specifically designed and engineered in order to provide maximum performance and engine protection for your Honda ATV. Positive filter sealing and ultra-high efficiency media ensure that no dust enters your engine.


1. Remove existing air filter
2. Install OTR filter mount support ring as shown and fully seat flange against tube
3. Install OTR grommet into existing filter support bracket (See Image)
4. Install filter and secure with supplied band clamp
5. Install and secure mounting bracket






OTR Support Ring

OTR Grommet



Existing Filter Support Bracket





Never oil an OTR filter as this will only degrade the filter's performance.

OTR FILTERS
605 Tower Road
Mundelein, IL 60060
800-263-8660